


FITTING




Inside fitting

Measure inside frame to frame left to right (mm) in three separate places as illustrated above a.b.c.

Measure inside frame to frame top to bottom (mm) in three separate place as illustrated above d.e.f.

Enter the smallest measurement of 3 for both the width and length of your blind. DO NOT make any deductions from these inside frame measurements.



Outside fitting

Measure outside frame to frame left to right (mm) as illustrated above a.

Measure outside frame to frame top to bottom (mm) as illustrated above b.

Overhang with an outside fitted blind you decide how much larger than the window frame you want the size of the blind to be.

A good example is to add 100(mm) to the width and 200(mm) to the length this means you fit the blind approximately 100(mm) above the frame whilst allowing it hang 100(mm) below the frame